Dipl.-Ing. Günther Kienitz

50935 Köln-Lindenthal Lindauer Straße 13 Telefon 02 21 - 43 33 00 Telefax 02 21 - 46 10 81 PILF.Koeln.Kienitz@t-online.de



Report No. : 140726-1

Applicant:	JONAS Farbenwerke GmbH & Co. KG				
	Frau Schiemann				
9 5 .0	Dieselstraße 42 – 44				
	42489 Wülfrath / Germany				
Application submitted	09.07.2014				
Application submitted:	09.07.2014				
Test subject:	How resistant is the coating with				
	>> JONAS Mattlatex <<				
	against disinfectants that are used in hospitals and physicians'				
	practices for the disinfection of surfaces?				
On-site inspection:					
Sample / specimen:	Wet sample				
	>> JONAS Mattlatex <<				
Date of report:	July 26, 2014				
Sampling procedure:officia	l neutral private X				

This test report refers to the test item that has been examined.

The test report comprises 6 pages of text.

Any publication, reproduction, translation or use of this test report for advertising purposes – whether unabridged, abridged or in excerpts – is subject to obtaining a written permission.

Dipl.-Ing. Günther Kienitz

50935 Köln-Lindenthal Lindauer Straße 13 Telefon 02 21 - 43 33 00 Telefax 02 21 - 46 10 81 PILF.Koeln.Kienitz@t-online.de



Report No.: 140726-1

Table of contents

9.9

Introduction	Page 1
Preparation of sample	Page 1
Examination	Page 1
Results	Page 2
Summary	Page 2
Disinfectants examined	Page 3
Abstract	Attachment

Dipl.-Ing. Günther Kienitz

50935 Köln-Lindenthal Lindauer Straße 13

Telefon 02 21 - 43 33 00 Telefax 02 21 - 46 10 81 PILF.Koeln.Kienitz@t-online.de



Report No.: 140726-1

Page -1-

Introduction

JONAS Farbenwerke GmbH & Co. KG, Dieselstraße 42 – 44 in 42489 Wülfrath submitted a wet sample

>> JONAS Mattlatex <<.

The aim was to test the coating material for its resistance to disinfectants used in hospitals and physicians' practices, following to application and subsequent drying.

Preparation of sample

Two gypsum plaster boards sized 0.60 m x 0.25 m were primed with water-dilutable isolating paint (130 g/m² on average). After good homogenization of the coating material the density was measured with the pycnometer according to DIN EN ISO 2811-1. The result was a density of 1.53 g/cm³. Following 24 hours of drying at room air conditions, ~ 20 °C/ 60 % relative humidity,

>> JONAS Mattlatex <<

was applied two times with a drying time of 10 hours in-between. The material was well homogenized both times. Total consumption ~ 232 ml/m^2 respectively 355 g/m^2 .

Examination

The disinfectants were prepared using the highest concentrations which, according to their specifications, offer the briefest time of action when used for the disinfection of surfaces. Also used in the examinations were two alcoholic solutions as ready-to-use products. Please refer to the attached list of products which include product name, concentration as well as the combination of active ingredients.

The resistance to disinfectants was tested after 14 days of drying of the coating


Individual volumes of approx. 0.5 ml of each disinfecting solution were applied to the filter paper scraps lying on the coating surface and immediately covered with an hour glass.



Dipl.-Ing. Günther Kienitz

50935 Köln-Lindenthal Lindauer Straße 13 Telefon 02 21 - 43 33 00 Telefax 02 21 - 46 10 81 PILF.Koeln.Kienitz@t-online.de





Page - 2-

Following an acting period of 1 hour respectively 3 hours the disinfectants were completely removed using paper towels. Then the stressed test surfaces were assessed under glancing light. Following the acting period of 3 hours the whole surface was rinsed with water and the test plates were dried. Another assessment was done after 24 hours of drying under room air conditions.

Results

After the charge of the test surfaces with the dilutable disinfectants the coated surfaces and / or the coating films in themselves showed neither changes in colour, nor bubble or crack formations or loss of adhesiveness.

Summary

The exposure of >> JONAS Mattlatex <<

coatings to disinfectants as used in hospitals and physicians practices (please refer to list) does not lead to neither changes in colour, nor formation of cracks or bubbles or loss of adhesiveness. This was confirmed in tests immediately after exposure times of 1 hour and 3 hours, as well as following full drying.

Also for the use of the alcohol ready-to-use solutions, Incidin® Liquid Spray and Bacillol® no damages to the surfaces were observed.

The tests were made following DIN EN ISO 2812-3 from 2012.

Cologne, dated 26th July, 2014



Dipl.-Ing. Günther Kienitz

50935 Köln-Lindenthal Lindauer Straße 13 Telefon 02 21 - 43 33 00 Telefax 02 21 - 46 10 81 PILF.Koeln.Kienitz@t-online.de



Report No.: 140726-1

Page - 3-

Following disinfectants were used for the examination:

Incidin ® Plus	concent. of 2 %	1	Henkel	glucoprotamin
Incidur ®	concent. of 2 %	2	Henkel	glyoxal, glutaral
Minutil ®	concent. of 0.5 %	3	Henkel	formaldehyde, glyoxal, glutaral
Incidin ® Extra N	concent. of 2 %	4	Henkel	glucoprotamin, benzalkonium chloride
Kohrsolin ®	concent. of 3 %	5	Bode	glutaral, (ethylenedioxy)dimethanol, 1,3-Bis(hydroxymethyl)urea, tetrahydro-1,3,4,6-tetrakis- hydroxymethyl)imidazo[4,5-d]— 2,5(1H,3H)-dion
Terralin ®	concent. of 0.5 %	6	S & M	benzalkonium chloride, phenoxy propanol
Buraton ® 10 F	concent. of 1 %	7	S & M	glyoxal, formaldehyde, glutardialdehyde, 2-ethylhexanal
Quartamon ® Med	concent. of 2 %	8	S & M	benzallkonium chloride
Incidin ® Liquid Spray	Ready-to-use solution	9	Henkel	2-propanol, 1-propanol, micro biocide ampho tensides
Bacillol ®	Ready-to-use solution	10	Bode	1-propanol, 2-propanol, ethanol, 1,6-dihydoxy-2,5-dioxahexane, mecetronium ethylsulfate



Dipl.-Ing. Günther Kienitz

50935 Köln-Lindenthal Lindauer Straße 13 Telefon 02 21 - 43 33 00 Telefax 02 21 - 46 10 81 PILF.Koeln.Kienitz@t-online.de



Testing of JONAS Mattlatex

Abstract of examination report of 26th July, 2014

Applicant:

JONAS Farbenwerke GmbH & Co. KG Frau Schiemann Dieselstraße 42 – 44 42489 Wülfrath / Germany

Test subject:

How resistant is the coating with

>> JONAS Mattlatex <<

against disinfectants that are used in hospitals and physicians' practices for the disinfection of surfaces?

Test result: neither The 8 dilutable disinfectants used for testing did not lead to

changes in colour, nor formation of cracks or bubbles or loss of adhesiveness in the gypsum plaster boards which had been primed with water-dilutable isolating paint.

Also for the use of the alcohol ready-to-use solutions, Incidin® Liquid Spray and Bacillol®, no damages to the surfaces were observed.

The tests were made following DIN EN ISO 2812-3 from 2012.

Cologne, dated 26th July, 2014

